


**GEOBELL**  
For GeoTag & AirTag

**ANVÄNDARMANUAL**  
**USER MANUAL**





**MEID**

**CE**   
**MEID027-2406-CN**

# MONTERINGSANVISNINGAR GEOTAG

1. Skruva lös skruvarna från GeoBell
2. Skruva bort locket på GeoBell och placera din GeoTag\* i det avsedda utrymmet (Bild 1)
3. Skruva tillbaka locket och använd de medföljande skruvarna (4 st) för att fästa locket ordentligt på plats. (bild 2)

**OBS! Överdra inte skruvarna.**



**\*GEOTAG SÄLJS SEPARAT**


# MONTERINGSANVISNINGAR STYRE

1. Placera GeoBell på styret (Bild 3).


Geobell passar styren med en omkrets på 22.2 - 25.2 mm.

**Tips!** Använd de medföljande avståndsmattorna för att reglera GeoBell till ditt styre.

2. Skruva fast GeoBell på styret med hjälp av den medföljande skruven (Bild 4)



(3)



(4)

Ø 22.2 - 25.4 mm

# UNDERHÅLL

1. Håll GeoBell ren och fri från smuts.
2. Kontrollera regelbundet att skruvarna sitter fast ordentligt.
3. Om ljudet från GeoBell blir svagt, kontrollera för eventuell smuts som kan blockera klangmekanismen och rengör vid behov.

## REGLER OCH FÖLJSAMHET



We Meid AB förklarar härmed att denna enhet uppfyller kraven enligt:

**RoHS och CE:** Produkten följer RoHS-direktivet 2011/65/EU samt IEC 62321, vilket begränsar användningen av farliga ämnen. Genom att uppfylla RoHS-kraven är produkten även CE-märkt, vilket innebär att den uppfyller alla väsentliga krav för hälsa, säkerhet och miljöskydd enligt EU-lagstiftning.

**REACH-förordningen** (EG) nr 1907/2006, som reglerar registrering, utvärdering, godkännande och begränsning av kemikalier inom EU.

En kopia av EU:s försäkran om överensstämmelse finns tillgänglig på [www.wemeid.com/compliance/](http://www.wemeid.com/compliance/)

## ÅTERVINNING

Lokala regler och bestämmelser kräver att produkten kasseras separat från hushållsavfallet. När produkten har tjänat ut sin tid måste den tas till en återvinningsstation som utsetts av lokala myndigheter. Separat insamling och återvinning av produkten vid kassering hjälper till att spara naturresurser och säkerställer att den återvinns på ett sätt som skonar hälsa och miljö.

## GARANTI OCH SUPPORT

Denna produkt omfattas av en 2-års garanti enligt EU:s konsument-skyddsdirektiv. Garantiperioden börjar på inköpsdagen och täcker material- och fabrikationsfel. Vid fel eller brist på produkten under garantiperioden, erbjuder vi kostnadsfri reparation eller utbyte. För att göra anspråk på garanti krävs ett giltigt inköpskvitto.



Om du behöver hjälp med din produkt, besök på **[www.wemeid.com](http://www.wemeid.com)** eller kontakta vår kundservice via e-post på **[support@wemeid.com](mailto:support@wemeid.com)**. Vid behov av reparation eller service, kommer vi att ge dig detaljerade instruktioner för retur och hantering.

Observera att garantin inte täcker skador orsakade av felaktig användning, olyckor, eller obehöriga modifieringar av produkten.

## ASSEMBLY INSTRUCTIONS GEOTAG

1. Unscrew the screws from GeoBell.
2. Unscrew the lid from GeoBell and place your GeoTag\* in the designated space (Image 1).
3. Reattach the lid and use the included screws (4 pcs) to securely fasten the lid in place (Image 2).

**Note! Do not overtighten the screws.**




**\*GEOTAG IS SOLD SEPARATE**

# HANDLEBAR ASSEMBLY INSTRUCTIONS


1. Place GeoBell on the handlebar (Image 3). GeoBell fits handlebars with a circumference of 22.2 - 25.2 mm.

**Tip!** Use the included distance rubber to adjust the GeoBell to your handlebar.

2. Secure GeoBell to the handlebar using the included screw (Image 4).



(3)



(4)

Ø 22.2 - 25.4 mm

## MAINTENANCE

1. Keep GeoBell clean and free from dirt.
2. Regularly check that the screws are securely fastened.
3. If the sound from GeoBell becomes weak, check for any dirt that may be blocking the chime mechanism and clean as needed.

## REGULATIONS AND COMPLIANCE



We Meid AB hereby declares that this device meets the requirements of:

**RoHS and CE:** The product complies with the RoHS Directive 2011/65/EU and IEC 62321, which restricts the use of hazardous substances. By meeting RoHS requirements, the product is also CE marked, indicating that it meets all essential health, safety, and environmental protection requirements under EU legislation.

**REACH Regulation** (EC) No 1907/2006, which regulates the registration, evaluation, authorization, and restriction of chemicals within the EU.

A copy of the EU Declaration of Conformity is available at [www.wemeid.com/compliance/](http://www.wemeid.com/compliance/)

## RECYCLING

Local regulations mandate that this product must be disposed of separately from household waste. When it reaches the end of its life, it should be taken to a designated recycling station. Proper collection and recycling at disposal help conserve natural resources and ensure the product is recycled in a way that protects both health and the environment.

## WARRANTY AND SUPPORT

This product is covered by a 2-year warranty according to the EU Consumer Protection Directive. The warranty period begins on the purchase date and covers material and manufacturing defects. In case of defects or shortcomings in the product during the warranty period, we offer free repair or replacement. A valid purchase receipt is required to claim the warranty.

If you need assistance with your product, visit [www.wemeid.com](http://www.wemeid.com) or contact our customer service via email at [support@wemeid.com](mailto:support@wemeid.com). For repair or service needs, we will provide you with detailed return and handling instructions.

**Note!** The warranty does not cover damage caused by improper use, accidents, or unauthorized modifications to the product.